

Signals in TSP Agreement	Signal Measurements, Reported to Server	Hino Engine Measurement Signal Name From Bosch v7r2_1_DEC	Cummins Engine Measurement Signal Name from Bosch BLV2r3	6/16/2022 Data Sample Rate in VMS BLScaldev7-J_Enginev2	Value sent from Bosch	Sample Value	Description of Data	Signal Information Notes
VIN	10 Secs., every 2 mins				ASCII (Text)	5PVA6JF062550022	17 character vehicle identification Number	Signal is not included in Hino or Cummins measurement stream but should be sent to TSP to identify vehicle
Hi Resolution Vehicle Distance	10 Secs., every 2 mins	Hi_Res_Vehicle_Distance	Hi_Res_Vehicle_Distance	10s	Decimal	Min 0 Max 42949667295	ECU Total Accumulated Mileage in km	Decimal Number sent from vehicle read in km
Total Fuel Used	10 Secs., every 2 mins	Total_Fuel_Used	Total_Fuel_Used	30s	Decimal	Min 0 Max 42949667295	ECU Total Accumulated Mileage in km	Decimal Number sent from vehicle read in km
Total Engine Hours	10 Secs., every 2 mins	Total_Engine_Hours	Total_Engine_Hours	10s	Decimal	Min 0 Max 42949667295	Lifetime Total amount of Fuel used as calculated by the Engine ECU in liters	Decimal Number sent from vehicle read in Liters
Total Idle Fuel Used	10 Secs., every 2 mins	Total_Idle_Fuel_Used	Total_Idle_Fuel_Used	10s	Decimal	Min 0 Max 210554000	Lifetime Total amount of Fuel used as calculated by the Engine ECU in liters	Decimal Number sent from vehicle read in Liters
Total Idle Hours	10 Secs., every 2 mins	Total_Idle_Hours	Total_Idle_Hours	10s	Decimal	Min 0 Max 210554000	Lifetime accumulation of engine running hours	Decimal Number sent from vehicle read in hours
Coolant Temp	10 Secs., every 2 mins	Engine_Coolant_Temp	Engine_Coolant_Temp	10s	Decimal	Min 0 Max 42949667295	Lifetime accumulation of engine running hours	Decimal Number sent from vehicle read in hours
Engine RPM	10 Secs., every 2 mins	Engine_RPM	Engine_RPM	10s	Decimal	Min 0 Max 42949667295	Life time calculation of the total amount of fuel used at Idle in Liters	Decimal Number sent from vehicle read in Liters
Park Brake Switch	10 Secs., every 2 mins	Parking_Brake_Switch	Parking_Brake_Switch	10s	Decimal	Min 0 Max 16383.75	Life time calculation of the total amount of fuel used at Idle in Liters	Decimal Number sent from vehicle read in Liters
Brake Switch	1 Sec., every 2 mins	Brake_Switch	Brake_Switch	1s	Decimal	Min 0 Max 16383.75	Life time calculation of the total amount of hours engine is idled in hours	Decimal number sent from vehicle read in hours
Cruise Set Switch	10 Secs., every 2 mins	Cruise_Set_Switch	Cruise_Set_Switch	10s	Decimal	1 On 0 Off	Life time calculation of the total amount of hours engine is idled in hours	Decimal number sent from vehicle read in hours
Cruise Resume Switch	10 Secs., every 2 mins	Cruise_Resume_Switch	Cruise_Resume_Switch	10s	Decimal	1 On 0 Off	Life time calculation of the total amount of hours engine is idled in hours	Decimal number sent from vehicle read in hours
Wheel-based Vehicle Speed	1 Sec., every 2 mins	Vehicle_Speed	Vehicle_Speed	1s	Decimal	Min -40 Max 250	Engine Coolant Temperature in Degrees Celcius	Decimal number sent from vehicle read in Celcius
PTO state	10 Secs., every 2 mins	PTO_State	TBD	10s	Decimal	Min -40 Max 250	Engine Coolant Temperature in Degrees Celcius	Decimal number sent from vehicle read in Celcius
Intake Air Pressure	10 Secs., every 2 mins	Intake_Air_Pressure	No Signal	10s	Decimal	Min 0 Max 16383.75	Engine Speed in Revolutions per Minute	Decimal number sent from vehicle in RPM
Common Rail Pressure	10 Secs., every 2 mins	Common_Rail_Pressure	No Signal	10s	Decimal	Min 0 Max 16383.75	Engine Speed in Revolutions per Minute	Decimal number sent from vehicle in RPM
Total Fuel with PTO	10 Secs., every 2 mins	Total_Fuel_with_PTO	Total_Fuel_with_PTO	10s	Decimal	1 On 0 Off	Parking Brake Switch status On or Off	Decimal number sent from vehicle On/Off signal
Total PTO time	10 Secs., every 2 mins	Total_PTO_Time	Total_PTO_Time	10s	Decimal	1 On 0 Off	Parking Brake Switch status On or Off	Decimal number sent from vehicle On/Off signal
DEF Level Dash Display	10 Secs., every 2 mins	DEF_Level_Dash	No Signal	10s	Decimal	1 On 0 Off	Service Brake Switch status On or Off	Decimal number sent from vehicle On/Off signal
DEF Tank Level Warning	10 Secs., every 2 mins	DEF_Tank_Level_Warning	Aftertrmtnt1DEFtnkLvlIndicator	10s	Decimal	1 On 0 Off	Service Brake Switch status On or Off	Decimal number sent from vehicle On/Off signal
SCR System Warning	10 Secs., every 2 mins	SCR_System_Warning	AftertrmtntSCR0PrtrIndcmntSverity	10s	Decimal	0,1,2,3	Cruise Control "set" switch status On or Off	Decimal number sent from vehicle On/Off signal
DEF Quality warning Flag	10 Secs., every 2 mins	DEF_Quality_Warning_Flag	DEF_Quality_Warning_Flag	10s	Decimal	1 On 0 Off	Cruise Control "set" switch status On or Off	Decimal number sent from vehicle On/Off signal
DPR PM Soot Level	10 Secs., every 2 mins	DPR_PM	DslPrctiteFilter1SootLoadPercent	10s	Decimal	0-100	Cruise Control "Resume" switch status On or Off	Decimal number sent from vehicle On/Off signal
Fuel Level	10 Secs., every 2 mins	Fuel_Level	FuelLevel1	10s	Decimal	0-100	Cruise Control "Resume" switch status On or Off	Decimal number sent from vehicle On/Off signal
Instant Fuel Consumption	10 Secs., every 2 mins	Instant_Fuel_Consumption	Instant_Fuel_Consumption	10s	Decimal	0-100	Cruise Control "Resume" switch status On or Off	Decimal number sent from vehicle On/Off signal
Accelerator Pedal Position	10 Secs., every 2 mins	APP	APP	10s	Decimal	0-100	Cruise Control "Resume" switch status On or Off	Decimal number sent from vehicle On/Off signal
Intake Air Temp (Airflow)	10 Secs., every 2 mins	Intake_Air_Temp	No Signal	10s	Decimal	0-100	Cruise Control "Resume" switch status On or Off	Decimal number sent from vehicle On/Off signal
DEF Level Actual %	10 Secs., every 2 mins	DEF_Level_Actual	Aftertrmtnt1DslExhstFldTankLevel	10s	Decimal	0-100	Cruise Control "Resume" switch status On or Off	Decimal number sent from vehicle On/Off signal
MIL Status	10 Secs., every 2 mins	MIL_Status	OBDMalfunctionIndicatorLampCmd	10s	Decimal	0-100	Cruise Control "Resume" switch status On or Off	Decimal number sent from vehicle On/Off signal
SVS Light	10 Secs., every 2 mins	SVS_Status	EnqAmberWarningLampCmd	10s	Decimal	0-100	Cruise Control "Resume" switch status On or Off	Decimal number sent from vehicle On/Off signal
WIF Light	10 Secs., every 2 mins	WIF_Light	WaterInFuelIndicator	30s	Decimal	0-100	Cruise Control "Resume" switch status On or Off	Decimal number sent from vehicle On/Off signal
DTC Engine Transmitted	Upon Event	DTC_Error_Code	DTC_Error_Code	Upon Event	Text	Cummins DTC Payload	Fault code, Severity, Time stamp, Description, etc.	
Ignition State	10 Secs., every 2 mins	Ignition_State	TBD	10s	TBD	Hino DTC Payload	Fault code, Severity, Time stamp, Description, etc.	
Harsh Braking events	10 Secs., every 2 mins	Harsh_braking_events	Harsh braking events	Upon Event	Decimal	1 On 0 Off		Calculated by Back End using vehicle speed
Harsh Acceleration events	10 Secs., every 2 mins	Harsh_acceleration_events	Harsh acceleration events	Upon Event	Decimal	1 On 0 Off		Calculated by Back End using vehicle speed
Trip Mileage	10 Secs., every 2 mins	TBD	TBD	10s	TBD	TBD		Calculated by Back End using vehicle speed
Fault Code Source	10 Secs., every 2 mins	TBD	TBD	10s	Text	TBD		Calculated by Back End using start and stop odometer value
GPS Location	10 Secs., every 2 mins	GPS	GPS	10s	Text	GPS Payload	Latitude, Elevation, Direction, Speed, etc.	
5MPH Alert after Stopped at 0 for 3+ seconds	Upon Event	TBD	TBD	Upon Event	TBD	TBD		Calculated by Back End using vehicle speed

DEF_Level_Dash	Decimal Value	Description
	1	0%
	2	5%
	3	10%
	4	25%
	5	40%
	6	55%
	7	70%
	8	85%
	9	100%

DEF_Tank_Level__Warning	Decimal Value	Description
	0	Off
	1	Flashing
	2	Low DEF
	7	Off

Afrtrtmnt1DEFtnklLvlIndicator	Decimal Value	Description
	1	On
	0	Off

AfrtrtmntSCROprtIndcmtSverity	Decimal Value	Description
	0	Off
	1	Inducement Level 1
	2	Inducement Level 2
	3	Inducement Level 3
	4	Inducement Level 4
	5	Inducement Level 5
	6	reserved
	7	N/A

SCR_System_Warning	Decimal Value	Description
	0	Off
	1	On
	2	Off
	3	Off

DPR_PM	Decimal Value	Description
	0	0%
	1	10%
	2	20%
	3	30%
	4	40%
	5	50%
	6	60%
	7	70%
	8	80%
	9	90%
	10	100%

```

HINO DTC ERROR CODE
"series":{
  "uid": "8e780ae3-5c3f-430e-9df2-dc9ec317ccbe",
  "seriesName": "DTC_Error_Code",
  "valueType": "DOUBLE",
  "description": "7TH INJECTOR FCV FUNCTIONAL ERROR",
  "severity": "High",
  "signalCollectionId": "aa2e2d28-15d9-43cd-acb3-1f10721a5f63",
  "sourceId": "84f5fbae-61c8-4d0b-9897-e18cd351f2ea",
  "sourceName": "v4r2",
  "unit": "",
  "protocol": "CAN_RAW",
  "type": "SIGNAL",
  "samplingRate": 10000
}, "dataPoints": [
  {
    "uniqueId": "0fada7ac-39ed-44fd-b1a2-2bf230e6e18d",
    "timeStamp": "2021-02-19T10:10:00.023Z",
    "value": "P0006"
  },
  {
    "uniqueId": "04abd73a-167f-4000-968d-479f5c7c603a",
    "timeStamp": "2021-02-19T10:10:10.023Z",
    "value": "P0006"
  }
]

```

```

CUMMINS DTC ERROR CODE
"series": {
  "uid": "8e780ae3-5c3f-430e-9df2-dc9ec317ccbe",
  "seriesName": "DTC_Error_Code",
  "valueType": "DOUBLE",
  "description": "Aftertreatment 1 Diesel Exhaust Fluid Tank Temperature - Data Erratic, Intermittent, or Incorrect",
  "severity": "Moderate",
  "signalCollectionId": "aa2e2d28-15d9-43cd-acb3-1f10721a5f63",
  "sourceId": "84f5fbae-61c8-4d0b-9897-e18cd351f2ea",
  "sourceName": "v4r2",
  "unit": "",
  "protocol": "CAN_RAW",
  "type": "SIGNAL",
  "samplingRate": 10000
}, "dataPoints": [
  {
    "uniqueId": "0fada7ac-39ed-44fd-b1a2-2bf230e6e18d",
    "timeStamp": "2021-02-19T10:10:00.023Z",
    "value": "1679"
  },
  {
    "uniqueId": "04abd73a-167f-4000-968d-479f5c7c603a",
    "timeStamp": "2021-02-19T10:10:10.023Z",
    "value": "1679"
  }
]

```

```

GPS
latitude: 42.878356,
elevation": 241.8520050048828,
"gpsTime": 1607948434000,
"direction": 358.3778381347656,
"gpsSpeed": 11.59,
"lastReadingTime": 0
}

```